


ADJUSTING THE TILT



1. To adjust the tilt, you will need to change where the ropes overhead are locked into that D shaped steel ring. To unlock, lift the ropes along with the pin away from the D-ring creating a slack of 1-1/2" (40 mm) for starters.

2. Pull on the back ropes (for more laid back) or the front ropes (for more upright) until all slack from step one is eliminated.

3. Retighten the ropes, sinching the locking pin.